



NOTES:

- Please use a torque wrench for all installations.
- Tighten headset to manufacturer's torque specs.
- Ensure ZERO GAP at both upper clamp interfaces.
- Before installing clamps onto handlebar, or stem onto steerer tube, ensure all surfaces are free of grease and debris.
- For more information, visit support.bythehive.com