BOSCH SPEED SENSOR VALVE ASSEMBLY

CAP CARRIER **VALVE BODY BOSCH SENSOR (OPTIONAL) RIM 0-RING BASE NUT**

WHEN TIRE IS INFLATED



TIGHTEN VALVE BEFORE INFLATE





